

Operating and Installation Guide

UNI-Control, AMATRON II, BMS 2000

on manure carts


Version: April 2002

Contents

1	Overview	3
1.1	Pump tank trailer	3
1.2	Vacuum tank trailer.....	3
2	System description.....	4
2.1	Pump tank trailer	4
2.2	Vacuum tank trailer.....	4
2.3	Technical data	5
2.3.1	Flow meter.....	5
2.3.2	Ball valve (By-pass valve for the pump trailer).....	5
2.3.3	Flat-side valve (cross-section control for vacuum tank trailer).....	5
2.3.4	Actuator	5
3	Installation instructions	6
3.1	UNI Control.....	6
3.2	Switch box	6
3.3	Signal distributor.....	6
3.4	16 channel coupler plug	8
3.5	Sensor X (Wheel)	8
3.6	Sensor Y (working position).....	9
3.7	Flow meter.....	9
3.8	By-pass valve (pump tank trailer)	10
3.9	Flat side valve (vacuum tank trailer)	11
3.10	Revolution sensor (pump tank trailer).....	12
4	Safety.....	13
4.1	Specified implementation	13
4.2	Safety instructions	13
5	Operating instructions	14
5.1	Switch box	14
5.2	Initial operation	15
5.3	Operating scheme	16
5.4	Description of the order, machine and operation data of and the memory.....	17

1 Overview

1.1 Pump tank trailer



Function:


Overdose control process:

- > UNI control closes the by-pass valve in proportion to the dosage error
- > Pressure in distribution system rises
- > Spread rate increases

Underdose control process:

- > UNI control opens the by-pass valve in proportion to the dosage error
- > Pressure in distribution system falls
- > Spread rate decreases

1.2 Vacuum tank trailer



Function:

Overdose control process:

- > UNI control closes the by-pass valve in proportion to the dosage error
- > Pressure in distribution system rises
- > Spread rate increases

Underdose control process:

- > UNI control opens the by-pass valve in proportion to the dosage error
- > Pressure in distribution system falls
- > Spread rate decreases

2 System description

Accurate lateral distribution is ensured when using towing tube distributors or slot devices.

Due to high traction power demands there are substantial rate fluctuations especially on hilly ground and where soil conditions vary frequently.

Fully automatic surface-related regulation of the spread rate using the UNI Control counteracts this problem. Even on hilly ground with highly varying traction power demands and the resulting changes in speed, an accurate dosage is guaranteed.

2.1 Pump tank trailer

Behind the pump there is a 3" by-pass to the tank. In this by-pass there is a 3" valve which can be adjusted via an actuator.

A magnetic inductive flow meter is installed in the tube in front of the towing tube distributor or slot device.

Once the machine data have been entered the operation process can begin. The current speed and spread rate are constantly displayed to the driver. If the UNI Control detects a deviation from the pre-set rate the actuator triggers the by-pass valve.

If the spread rate is too low, the by-pass valve is closed a little. The system pressure is raised and the spread rate is increased.

If the computer detects that the spread rate is too high, the valve is opened so that the system pressure is lowered and the spread rate reduced.

2.2 Vacuum tank trailer

In the connection to the towing tube distributor or the slot device an additional flat-side valve is installed. This can be adjusted by the UNI Control via an actuator.

A magnetic inductive flow meter is installed in the tube in front of the distributor.

Once the machine data have been entered the operation process can begin.

The speed and the current spread rate in cbm/ha are displayed to the driver.

If the UNI Control recognizes that the spread rate is too low, the actuator opens the flat-side valve further. This causes the pressure at the flat-side valve to be lowered and in the distributor system to be increased.

The spread rate is increased in this way.

If the UNI Control detects a too high spread rate, the flat-side valve is closed a little.

The spread rate is decreased.

2.3 Technical data

2.3.1 Flow meter

- Measuring range: nominal width 100 = 0.3 - 3 cbm / min.
 nominal width 125 = 0.4 - 4 cbm / min.
 nominal width 150 = 0.5 - 5 cbm / min.
- Measuring tolerance: +/- 2 % from the measured rate
- Number of impulses/cbm: 10 000
- minimum conductivity of the measured content > 5 µs/cm
- Ambient temperature: - 10°C bis + 60°C
- max. pressure permitted: 10 bar
- Sandwich connection nach DIN
- Voltage supply: 10 - 16 V = DC

These specifications are taken from the manufacturer's data sheet.

2.3.2 Ball valve (By-pass valve for the pump trailer)

- 3" for a pumping output of up to 3 cbm/min.
- 4 " for pumps with a required output of more than 3 cbm/min.

2.3.3 Flat-side valve (cross-section control for vacuum tank trailer)

Standard flat-side valves matching the respective tube diameter are used.

2.3.4 Actuator

The actuator LA 30.3-200-12 VDC/TD from Linak is used. The stroke is 200 mm.

The max. current consumption is stated to be 18 amperes.

The actuator is protected by a cut-out fuse in the signal distributor.

3 Installation instructions

3.1 UNI Control

Please refer to the relevant operating and installation instructions for the installation of the UNI Control computer.

3.2 Switch box


The switch box is mounted on to the cross pole on the UNI Control in the tractor. Please make sure that it sits securely and that the electrical connection from the UNI Control to the switch box is safe. The voltage supply is via the constant current socket on the basic console.

3.3 Signal distributor


The signal distributor is to be installed in an easily accessible position on the manure cart using the enclosed M4 x 25 screws. The positioning should be chosen so that the distance to the sensors or to the actuators is as short as possible. The PG screw fittings on the distributor (sensor and actuator cable) should point downwards.

All cables can be shortened. However they must be fitted with end sleeves for the strands. The lid must be closed carefully after installation.

Signal distributor - manure



Signal distributor - 2002




3.4 16 channel coupler plug

The bottom part of the 16 channel coupler plug is to be installed in an easily accessible position at the front of the manure cart, e.g. on the shaft.

The connecting cable from the switch box to the signal distributor is cut through at this point. The cable from the signal distributor is wired with the pin in the lower part of the coupler plug, lead 1 to pin 1 etc. End sleeves for the strands must be used.

The cable to the switch box can be shortened if necessary. Installation in the upper section (socket) of the coupler plug is carried out in the same way as in the lower part.




3.5 Sensor X (Wheel)

The UNI Control needs a signal for the calculation of the distance travelled. This should be slip-free if possible.

As well as impulse recording from the tractor's front wheel or cardan shaft and measurement using a radar device, speed can also be taken from the wheel of the manure cart or from a free-running wheel.

The magnets are installed in the wheel shell using the enclosed V4A screws. They must be distributed as evenly as possible. The distance travelled from impulse to impulse must not exceed 60cm. The number of magnets depends on the size of the wheel.



Calculation:

Wheel circumference _ 60cm = number of magnets

e.g.:

256cm _ 60cm = 4.27 = 5 magnets

The sensor X is mounted vibration-free to a static machine part using the enclosed fixture. The sensor must point to the side of the magnet painted red (south pole) at a distance of 5 - 10 mm.

The cable is connected in the distributor at the 3 clamps marked "wheel".

brown = br = 12 volt
white = ws = ground
green = gn = signal

3.6 Sensor Y (working position)

If the opening and closing of the education valve is not carried out by the UNI Control switch box, then the sensor Y "working position" is to be installed at the education valve.

A magnet is installed at the valve lever. The sensor Y is mounted to a static machine part using the enclosed fixture. In working position the sensor must point to the red side of the magnet at a distance of 10 – 20 mm. The control lamp "working position" lights up on the UNI Control.

The cable is connected in the distributor at the clamps marked "working position".

white = ws = ground
green = gn = signal

3.7 Flow meter

The flow meter is positioned in the tube to the distributor system in such a way that only the quantity which is actually spread flows through the flow meter. In front of the flow meter there must be a straight piece of tubing with a length of 10 x nominal width (10 x 100 mm = 1 m). Behind the flow meter a straight piece of tubing with a length of 3 x nominal width is required.

The tube must have the same nominal width as the flow meter. The flow meter is to be mounted joint-free between the flanges so that no liquid turbulence can develop. The direction of the flow, marked with an arrow on the flow meter, must be adhered to.

The flow meter can be mounted in a horizontal or perpendicular positioned tube. Preference should be given to the perpendicular position, as air locks in the liquid have a less negative effect on measurement accuracy.

Grounding the flow meter

The ground wire from the casing must be connected carefully to the adjacent flange.

In the flange a 5 mm hole is to be bored. The ground wire is connected with the enclosed M5 x 25 V4A screws.

Connection in the distributor.

a) Flow meter

The cable from the flow meter is connected in the distributor at the clamps marked "flow meter".

green-yellow = gnge = operation ground
 wire 4 = operation ground
 wire 3 = + 12 volt
 wire 2 = signal
 wire 1 = ground

The lid of the flow meter must not be opened. In the case of violation the guarantee is no longer binding.


In addition the enclosed manufacturer's operating instructions should be heeded.

b) Inductive pump rotation sensor (only with pump tank trailer) to determine the spread rate

brown = br
 black = sw
 blue = bl

3.8 By-pass valve (pump tank trailer)

The by-pass valve is installed in the by-pass between the pump flow meter supply tube and the manure cart. Its purpose is to redirect the surplus quantity from the pump back to the tank. The optimal positioning is best determined on site at the tank.



The actuator should be installed so that with an retracted or extended position of the ball valve's lever an angle of 25° is formed to the actuator. The engine must run internally on the end stoppers.

The cable from the actuator is connected in the distributor box under ""regulation" at the clamps marked "+ br" und "- br".

By-pass valve function test

- Switch on switch box
- Switch "Manual/automatic" switch to "manual"
- Press "+" from the "+/-" keys


The by-pass valve should now close. Should it open instead, the two wires from the actuator in the signal distributor must be replaced.

3.9 Flat side valve (vacuum tank trailer)

The flat side valve is installed in the lead to the distributor system. It's purpose is to supply the distributor system only with as much liquid as necessary to adhere exactly to the pre-set quantity to be spread. .

The optimal positioning is best decided on-site at the tank. In some cases it is practical to install the rcontrol valve (flat side) directly behind the stop valve (flat-side).

The following construction has proved to be satisfactory in practice.



The measurements must be determined on-site depending on the flat-side valve. The engine should run internally on the minimum and maximum limit

Note!

The construction gap should be kept to a minimum. The cable from the actuator is connected in the distributor system under "regulation".

Flat-side valve function test:

- Switch on switch box
- Switch "Manual/automatic" switch to "manual"
- Press "+" from the "+/-" keys

The flat-side valve should now open. Should it close instead the two wires from the actuator in the signal distributor must be replaced.

3.10 Revolution sensor (pump tank trailer)

If required the current power take-off shaft r.p.m. can be displayed on the UNI Control simply by pressing a key.

Sensor revolution power take-off shaft (Art. No.: 302 580)

For this purpose the sensor is to be installed at the pump drive.

Installation:

- The plastic disc with the integrated magnet is pushed on to the pump's drive shaft and secured with the grub screws.
- The sensor is installed using the enclosed fixture. It must point towards the magnets. The distance is to be between 3 and 5 mm.

The cable is connected in the signal distributor under "pump revolutions"

Brown	= br	= + 12 volt
white	= ws	= ground
green	= gn	= signal

4 Safety

4.1 Specified implementation

The device is specified exclusively for use in agriculture. Any application outwith this area is regarded as unspecified.

The manufacturer does not accept liability for damage to persons or property resulting from unspecified use. In such cases all risks are the responsibility of the user.

Specified implementation also includes adhering to the operation and maintenance conditions stipulated by the manufacturer in the operating instructions.


Relevant accident prevention regulations as well as other generally recognized safety, industrial-medical and road traffic rules are to be adhered to. In addition the manufacturer accepts no liability in cases where arbitrary modifications have been made to the system.

4.2 Safety instructions

Before working on the electrical system or carrying out any welding operations on the tractor or on an attached implement, the battery connection must be interrupted.

5 Operating instructions

5.1 Switch box



- Switch "Voltage on-off "
- The voltage for the switch box and signal distributor is switched on and off here.
- Switch "Manual/Automatic" and "+/-" keys
- If the "Manual/Automatic" switch is at manual, the control valve can be operated using the +/- keys.
 - + Spread rate is increased
 - Spread rate is decreased

In the "Automatic" position the control valve is regulated by the UNI Control.

- Main switch
- This switch is only available when the stop valve on the manure cart is regulated by an electric motor or electrohydraulically.

5.2 Initial operation


Before initial operation the layout of the cables and the installation of the sensors and the actuators should be checked.

The first test should be carried out with water. .

Procedure:

- Enter machine and order data in to the UNI Control (5.4) and set the pre-set rate to 0.
- Start the order (5.4.)
- Set the switch box to manual operation.
- Select the data block "operation data".
- Drive the tractor. The control lamp "journey" should flash on the UNI Control. The speed is shown on the display.
- Switch on the manure tank. The control lamp "working position" should light up on the UNI Control. The spread rate is shown on the display (cbm/ha).
- Vary the quantity using the +/- keys on the switch box. The display (cbm/ha) corresponds to the +/- key position.
- Enter a pre-set rate e.g. 20 cbm/ha in the UNI -Control (order data). The computer should now maintain this pre-set rate even when speed varies.
If the regulation is too sluggish the control constant (machine data) should be increased.
Experience at present shows the optimal rate to be between 20 and 40.
- Repeat the test with manure.

5.3 Operating scheme



5.4 Description of the order, machine and operation data of and the memory

The operation procedure for initial operation is described here. The display together with the adjacent soft keys are depicted:

Left : User guidance and information display

Right : Description of the soft keys

Abbreviations of the data blocks

Me = Menu selection

Au = Order data block


Sp = Memory data block

Ma = Machine data block

Ar = Operation data block

Note!


Error-free operation with the manure cart is guaranteed as of 07.01.1992.
Manure cart program



Left:
Program creation date and version,
name of the machine connected

Right:
Select the required language.

Menu selection (Me)



Left:
"Menu selection" displayed.
Press the T1 key "Menu" from any display position in order to switch to the menu selection.
Then press the T1 to T4 keys to select the data block required.

Right:
Press the T1 key to go to the order data.
Press the T2 key to go to the memory.
The orders which have been already processed are displayed here (max. 20).
Press the T3 key to go to the machine data.
Press the T4 key to go to the operation data.

Order data block (Au)

Order	Menu	T1	T2	T3	T4
No: 5	Start				
Name / Address:					
MEYER A. BERG	Continue				

Left:
Order number, automatically allocated by the board computer, is displayed.
Enter the customer's name or the field using the alphabetical keyboard.
Note: Press the enter key to end the entry!

Right:
Press the T1 key to go to menu selection.
With the T2 key the order is started (without entry of the set rate and comment), automatic move to the operation data.

Order	Menu	T1	T2	T3	T4
Applic. rate	Start				
Set rate					
20 cbm / ha	Continue				

Left:
Enter the required set rate using the decimal keyboard.

Right:
Press the T1 key to go to menu selection.
With the T2 key the order is started (without entry of the comment, automatic move to the operation data.

Order	Menu	T1	T2	T3	T4
Comment:	Start				
Light rain					
	Continue				


Left:
Any text can be entered using the alphabetical keyboard.
It will be stored as comment.

Right:
Press the T1 key to go to menu selection.
With the T2 key the order is started, automatic move to the operation data.
Press the T4 key to proceed to the next display.

Order	Menu	T1	T2	T3	T4
Machine	Start				
No: 1	Delete				
Field sprayer	Continue				


Left:
With the initial operation of each machine, the machine number is automatically allocated and also later automatically selected, i.e. no entry is needed! If however there is a 2nd field sprayer with different machine data the next free machine number is to be entered for the 2nd sprayer. In order to activate the 2nd field sprayer's machine data, its number will be entered using the decimal keyboard after connecting.

Right:
Press the T1 key to go to menu selection.
With the T2 key the order is started, automatic move to the operation data.
With the T3 key (delete) the machine data of the selected machine can be deleted.
Press the T4 key to go to menu selection.




Left:
After pressing the enter key the determined rate is displayed.

Right:
Press the T1 key to go to menu selection. Calibration can be repeated by pressing the T3 key.
Press the T4 key to proceed to the next display.




Left:
Enter the working width using the decimal keyboard.

Right:
Press the T1 key to go to menu selection. Press the T4 key to proceed to the next display




Left:
Enter the impulses/cbm using the decimal keyboard. The flow meters are calibrated to 10.000 impulses/cbm.

Right:
Press the T1 key to go to menu selection. If required calibration of the flow meter can be selected by pressing the T3 key. Press the T4 key to proceed to the next display.



Description of the calibration process
Right:
The calibration process can be interrupted by pressing the T3 key.

After the 1. impulse



When the manure cart has been switched on the 1st impulse from the flow meter appears on the display opposite. The impulses are counted. The contents of one tank filling have to be spread. Before air can get through the flow meter, close the slide valve.

After the tank contents have been spread determine the exact amount and enter using the decimal keyboard.

Left:
After pressing the enter key "(=)" the computer calculates the rate "impulses/cbm" and displays it.

Right:
Press the T1 key to go to menu selection. Press the T4 key to proceed to the next display.


The volume meter's impulse count should be checked a few times each year and especially at the beginning of each season.

Left:
In order to determine the residue in the tank, the content and if required an alarm threshold value can be entered here.

Right:
Press the T1 key to go to menu selection. Press the T4 key to proceed to the next display.

Left:
As with the field sprayer it is possible to operate the tank cart with several boom sections. If there is no boom section switch, enter a 1 under "boom section 1". The "boom section 2" is then acknowledged with a 0.

Right:
Press the T1 key to go to menu selection. Press the T4 key to proceed to the next display.




Left:

Up to a maximum of 10 boom sections can be taken into account.
If there are e.g. 2 boom sections, the 3rd boom section is set to 0 using the decimal keyboard.

Right:

Press the T1 key to go to menu selection.
Press the T4 key to proceed to the next display.




Left:

The control constant is entered using the decimal keyboard. If regulation is too sluggish, the rate has to be increased. In the case of saturation, i.e. with a set-rate of 20cbm/ha there is regulation from 16cbm/ha to 23cbm/ha then to 18cbm/ha etc., then the control constant is too high. The entered cart rate must be reduced. Depending on the manure values varying from 10 to 40 are possible.

Rechts:

Press the T1 and T4 keys to go to menu selection.

Operation data block (Ar)




Left:

The current order number is displayed.

Right:

Press the T1 key to go to menu selection.
The order as well as operation time is started when the T2 key is pressed.
When the T3 key is pressed the order will not be started. The journey can be continued without the working position.




Left:

Relevant information is displayed here during the operation process:
speed, current spread rate, pre-set deviation from the set rate entered, the remaining width when working with boom sections.


Right:

Press the T1 key to go to menu selection.
Press the T2 key to go to the end of the order.
Press the T3 key for the tank content data
Press the T4 key for further operation data.




Left:
Display of the current spread rate in
cbm/min.

Right:
Press the T1 key to go to menu selection.
Press the T4 key to go to the operation
data.




Left:
Display of the current pre-set spread rate,
the residue in the tank and the prognoses
for the distance and area, which have still
to be processed using the remaining amount.
Using the +/-10% keys the pre-set rate can
be set so that the prognoses correspond with
the actual conditions and there is no
residue!

Right:
Press the T1 key to go to menu selection.
Press the T3 key for the tank content data.
Press the T4 key to go to the operation
data.



Left:
The new tank content can be entered here.


Right:
The T1 key acknowledges that the tank is
empty.
The T2 key is pressed when the tank has been
filled up.
Press the T4 key to go to the operation
data.
Any further information required can be
entered using the decimal keyboard.



Left:
The order can be ended and stored here.

Right:
Press the T1 key to go to menu selection.
The current operation data can be selected
by presing the T2 key.
The T3 key is used to store the calculated
data.

Memory data block



Left:


The last order to be stored is automatically displayed.

Right:

Press the T1 key to go to menu selection. By pressing the T2 key all orders in the memory are deleted.

The previous order is displayed when the T3 key is pressed.

The order, machine and operation data of each order can be selected by pressing the T4 key.




Left:

Further data concerning order number 5 are displayed.

Right:

Press the T1 key to go to menu selection.

The order, machine and operation data of each order can be selected by pressing the T4 key.




Left:

Display of operation time
Operation time "Machine" runs when the machine is in working position.
Operation time "tractor" runs when the speed exceeds 1 km/h.
Operation time "driver" counts from board computer switch-on.

Rechts:

Press the T1 key to go to menu selection. The order, machine and operation data of any order can be selected by pressing the T4 key.




Left:

Any comments entered are shown on the display.

Right:

Press the T1 key to go to menu selection.


Press the T4 key to go to memory 4.



Left:
All orders existing in the memory
can be deleted.


Right:
The memory will not be deleted when the T2
key is pressed.
It is deleted using the T3 key.
Back to menu selection.

Alarm display



Alarm display as soon as the pre-set rate
can no longer be maintained.

Calculator function



Left:
The calculator function is selected via
the +, -, x or ÷ keys.
The calculator can be used during operation.

Rechts:
Press the T4 key to go back to the program.

Functional data

The 3 function keys beside the decimal keyboard enable required rates to be displayed at any time simply by pressing a key.

